


**Montageanleitung
Assembly Instructions
Instructions de montage
Istruzioni di montaggio**





Karcher GmbH
Design-Beschläge
Raiffeisenstr.32
74906 Bad Rappenau
+49-7264-91640
+49-7264-916440
mail@karcher-design.de
www.karcher-design.de


EGS210Q OS



EGS210Q S9



EGS210Q OS




EGS210Q S9

Bohrschema für Glastüren

Drilling diagram for glass doors

Schéma de perçage pour portes en verre

Schema di foratura per porte in vetro




Fallen-Varianten

Latch variants

Types de pènes

Varianti di scrocci







Demontage des Schlosskastens

Disassembling the lock

Démontage de la serrure

Smontaggio della serratura



Falle drehen falls erforderlich!


Turn latch if necessary!

Tourner le pêne si nécessaire!


Ruotare lo scrocco, se necessario!




①



②



③



Für nach außen öffnende Türen!


For outward opening doors!

Pour les portes s'ouvrant vers l'extérieur!


Per porte con apertura verso l'esterno!




④




⑤



⑥



7



Zwischen Glas und Schloss kleben!
Stick between glass and lock!
Coller entre le verre et la serrure!
Incollare tra il vetro e la serratura!




Pfeil zeigt nach oben!
Arrow points upwards!
La flèche pointe vers le haut!
La freccia punta verso l'alto!




S9 / OS

8




9




S9 / OS

10



S9 / OS

11




S9 / OS

SW 3


(2x)

12



S9 / OS

13




S9

Modellauswahlhilfe
Model selection guide
Guide de sélection des modèles
Guida alla scelta del modello



Karcher GmbH
 Design-Beschläge
 Raiffeisenstr.32
 74906 Bad Rappenau
 +49-7264-91640
 +49-7264-916440
 mail@karcher-design.de
 www.karcher-design.de




EGS210Q S9R

⑦ - ⑬

EGS210Q OS

⑦ - ⑫




EGS210Q S9R

① - ⑬

EGS210Q OS

① - ③ ⑦ - ⑫




EGS210Q S9L

⑦ - ⑬

EGS210Q OS

① - ③ ⑦ - ⑫



EGS210Q S9L

① - ⑬

EGS210Q OS

⑦ - ⑫